
ZENIT




antoniolupi


lifestyle




1_ Cut a hole in the sospende ceiling.



2_ Connect the water pipe to the showerhead making sure that it is firmly inserted.



3_ Insert the showerhead by moving the two docking levers upwards.




4_ Gently release the two fixing levers, thus blocking the showerhead to the suspended ceiling.




5_ To inspect the cartridge with nozzles, use the key supplied to unscrew it from the body of the showerhead, after maintenance has been completed reinsert the cartridge by screwing it in using the appropriate key.


NOTES




1_ Make a hole in the false ceiling.




2_ Connect the electrical wires of the lamp to the trasnformer previosly installed.



3_ Insert the lamp in the false ceiling, pushing upwards the two locking levers.



4_ Release gently the two locking levers thus blocking the lamp to the false ceiling.




5_ Electric scheme.

NOTE










*

I cavetti sono montati con terminali quindi anche l'alimentatore dovrà essere dotato di cablaggio con lo stesso tipo di terminali. (Fig. 1)
The cables are mounted with terminals and the power supply must also be equipped with cables with the same type of terminals. (Fig. 1)



NOTE

IT_RICAMBIO AREATORE007 - kit areatore spray 1” con chiavetta

EN_SPARE PART AREATORE007 - 1” spray aerator kit with key

FR_PIÈCE DE RECHANGE AREATORE007 - Kit aérateur spray 1” avec clé

ES_RECAMBIO AREATORE007 - Kit aireador spray 1” con llave

DE_LÖSUNGEN AREATORE007 - 1 Zoll-Perlator-Set mit Schlüssel

RU_ЗАПЧАСТИ AREATORE007 - Комплект аэратора-для распылителя 1, с ключом для установки

NOTE

IT_RICAMBIO AREATORE008 - kit areatore chiodo 1” con chiavetta

EN_SPARE PART AREATORE008 - 1” nail jet aerator kit with key

FR_PIÈCE DE RECHANGE AREATORE008 - Kit aérateur gros jet 1” avec clé

ES_RECAMBIO AREATORE008 - Kit aireador para chorro laminar 1” con llave

DE_LÖSUNGEN AREATORE008 - 1 Zoll Laminarstrahl Perlator Set mit Schlüssel

RU_ЗАПЧАСТИ AREATORE008 - Комплект аэратора для ламинарной струи 1″ с ключом

NOTE

NOTE

READ CAREFULLY THE INSTRUCTIONS GIVEN IN THE FOLLOWING MANUAL
Keep rigorously to the indications given in the manual for proper maintenance of the product.
POSITIONING
For internal use only.
Do not install the lamp near heated sources like radiators, heaters or other similar sources.
The installation of the lamp requires qualified personnel.
INSTALLATION
To connect the electrical parts, the support of qualified personnel with electrotechnical experience is required"; "When installing the product you must use adequate tools.
During installation it is necessary to pay close attention to the risk of electrical shock.
We recommend the installation of a bipolar switch to allow the electrical sectioning of the circuit.
Make the electrical connections as per the descriptive diagram in the present manual.
USE
Do not modify or alter the original conditions of the lamp. Any tampering can compromise its safety.
Do not use the lamp for other purposes than what it is intended for.
MAINTENANCE
For every sign of wear or malfunctoning call immediately the company Antonio Lupi Design S.p.A.
All components of the lamp must be promptly replaced in the event of damage.
The light source contained in this product must be replaced by qualified personnel.
REMOVAL AND DISPOSAL
During the removal of the product, all necessary precautions must be taken to avoid the risk of electric shock.
The removed product must then be disposed of according to all legal requirements as special waste.



EN_This product contains a light source with energy efficiency class < F >

IMPORTANT
For cleaning consult the technical data sheet downloadable from our website www.antoniolupi.it